


# Wireless Thermostat (WTS10)

## Override Guide



### To override the Auto program:

- ① Press the ▲ or ▼ button to activate the display.
- ② Press the ▲ to raise or ▼ button to lower both the Heat and Cool set points.
- ③ Confirm the settings by pressing the middle button.

### To change the individual Mode settings:

- ① Press the ▲ or ▼ button to activate the display.
- ② Press the - button to select Heat/Cool mode; press the + button to select the Fan mode.
- ③ Press the ▲ or ▼ button to select the mode.
- ④ When the desired mode appears, press the middle button to CONFIRM.
- ⑤ Press the ▲ button to raise or ▼ button to lower the set point for the currently selected mode.